

## Contents

Preface	vii
<b>1 / Introduction, Materials, and Properties</b>	<b>1</b>
Reinforced Concrete Structures. Historical Background. Concrete. Cement. Aggregates. Admixtures. Compressive Strength. Tensile Strength. Modulus of Elasticity. Creep and Shrinkage. Concrete Quality Control. Steel Reinforcement. <i>Selected References.</i>	
<b>2 / Design Methods and Requirements</b>	<b>22</b>
Ultimate Strength and Working Stress Design Methods. Working Stress Method. Ultimate Strength Method. Comments on Design Methods. Safety Provisions. Overload Provisions for Various Load Combinations. Building Code. Handbooks. Dimensions and Tolerances. Accuracy of Computations. <i>Selected References.</i>	
<b>3 / Strength of Rectangular Sections in Bending</b>	<b>32</b>
General Introduction. Basis of Ultimate Flexural Strength. Whitney Rectangular Stress Block. Investigation of Rectangular Sections in Bending with Tension Reinforcement Only. Compression Reinforcement. Balanced Ratio of Reinforcement at Ultimate Strength. Design of Rectangular Sections in Bending with Tension Reinforcement Only. Practical Selection for Beam Sizes, Bar Sizes, and Bar Placement. Investigation of Rectangular Sections in Bending with Both Tension and Compression Reinforcement. Criterion for the Compression Steel Yield Condition. Design of Rectangular Sections in Bending with Both Tension and Compression Reinforcement. <i>Selected References. Problems.</i>	
<b>4 / Rectangular Sections in Bending under Service Load Conditions</b>	<b>75</b>
General Introduction. Fundamental Assumptions. Equilibrium Conditions. Stress-Strain Relations. Method of Transformed Section. Investigation for Safety of Rectangular Sections in Bending with Tension Reinforcement Only. Underreinforced, Ideally Reinforced, and Overreinforced Sections. Design of Rectangular Sections in Bending with Tension Reinforcement Only. Design of Rectangular Sections in Bending with Both Tension and Compression Reinforcement. Investigation for Safety of Rectangular Sections in Bending with Both Tension and Compression Reinforcement. Serviceability—Deflections. Serviceability—Flexural Crack Control. Nonrectangular Sections in Bending. <i>Selected References. Problems.</i>	

## 5 / Shear Strength, Inclined Cracking, and Web Reinforcement

Introduction. Shear Stress. The Combined-Stress Formula. Behavior of Beams without Web Reinforcement. Shear Strength of Beams without Web Reinforcement. Function of Web Reinforcement. Shear Strength of Beams with Web Reinforcement. Lower and Upper Limits for Amount of Web Reinforcement. Critical Section for Nominal Shear Stress Calculation. Shear Provisions for Beams—1971 ACI Code. Working Stress Method—1971 ACI Code. Shear Strength of Beams—Design Examples. Shear Strength of Members under Combined Bending and Axial Load. Deep Beams. Brackets and Corbels. Shear-Friction. *Selected References. Problems.*

## 6 / Bond Stress and Development of Reinforcement

184

General. Anchorage Bond. Flexural Bond. Flexural Bond Stress in a Group of Tension Bars. Flexural Bond Stress in Compression Reinforcement. The Nature of Bond Failure. Inaccuracies in Flexural Bond Stress Computation. Moment Capacity Diagram—Bar Bends and Cutoffs. Basic Development Length for Tension Reinforcement. Factors to Modify Basic Development Length. Development Length for Compression Reinforcement. Development Length for Bundled Bars. Equivalent Development Length of Standard Hooks. Bar Cutoffs in Negative Moment Region of Continuous Beams. Bar Cutoffs in Positive Moment Region of Continuous Beams. Bar Cutoffs in Uniformly Loaded Cantilever Beams. Development of Reinforcement at Simple Supports and at Points of Inflection. Anchorage of Web Reinforcement. Tension Lap Splices. Welded Tension Splices and Other Positive Connections. Compression Lap Splices. Compression End Bearing Connections, Welded Splices, and Positive Connections. Design Examples. *Selected References. Problems.*

## 7 / Continuity in Building Frames of Reinforced Concrete

243

Common Building Frames. Positions of Live Load. Method of Analysis. ACI Moment Coefficients. ACI Moment Diagrams. Design Shears. *Selected References. Problems.*

## 8 / Design of One-Way Slabs

Definition. Design Methods. Thickness of Slab. Choice of Reinforcement. Continuity Analysis. Shrinkage and Temperature Reinforcement. Bar Details. *Selected References. Problems.*

## 9 / T-Sections in Bending

T-Sections. Effective Flange Width. Investigation of T-Sections in Bending—Ultimate Strength Method. Design of T-Sections in Bending—Ultimate Strength Method. Investigation of T-Sections in Bending—Working Stress Method. Design of T-Sections in Bending—Working Stress Method. *Selected References. Problems.*

## 10 / Continuous Floor Beams and Girders

Introduction. Size of Beam Web. Continuous Frame Analysis for Beams. Choice of Longitudinal Reinforcement in Beams. Web Reinforcement in Beams. Details of Bars in Beams. Size of Girder Web. Continuous Frame Analysis for Girders. Choice of Longitudinal Reinforcement in Girders. Redistribution of Moments—Introduction to Limit Analysis. *Selected References. Problems.*

## 11 / Concrete Joist Floor Construction

General Discussion. Design of Concrete Joist Floors. *Selected References. Problems.*

**12 / Retaining Walls**

Types of Retaining Structures. Forces on Retaining Walls. Earth Pressure Theories. Practical Treatment of Soil Pressure. Stability Requirements. Preliminary Proportioning of Cantilever Walls. Design Example—Cantilever Retaining Wall. Counterfort Retaining Walls. *Selected References. Problems.*

**13 / Members in Compression and Bending**

389

Introduction. Types of Columns. Behavior of Axially Loaded Columns. Safety Provisions. Concentrically Loaded Short Columns. Minimum Eccentricity. Length Effects. Lateral Ties. Spiral Reinforcement and Longitudinal Bar Placement. Limits on Percentage of Reinforcement. General Discussion on Combined Bending and Axial Load. Balanced Condition—Rectangular Sections. Balanced Condition—Circular Sections with Round Core. Ultimate Capacity Controlled by Compression—Rectangular Sections. Ultimate Capacity Controlled by Compression—Circular Sections with Round Core. Ultimate Capacity Controlled by Tension—Rectangular Sections. Ultimate Capacity Controlled by Tension—Circular Sections with Round Core. Design for Ultimate Strength—Region I, Minimum Eccentricity. Design for Ultimate Strength—Region II, Compression Controls ( $e_{min} < e < e_b$ ). Design for Ultimate Strength—Region III, Tension Controls ( $e > e_b$ ). Working Stress Method. Cracked-Section Analysis for Large Eccentricity Rectangular Tied Columns. Cracked-Section Analysis for Spirally Reinforced Circular or Square Sections with Round Core. Cracked-Section Analysis by Successive Approximation—Wessman Method. Biaxial Bending and Compression. *Selected References. Problems.*

**14 / Deflections**

Deflections—General. Deflections for Elastic Sections. Modulus of Elasticity. Moment of Inertia. Instantaneous Deflections in Design. Creep Effect on Deflections under Sustained Loading. Shrinkage Effect on Deflections under Sustained Load. Creep and Shrinkage Deflection—1971 ACI Code Method. Creep and Shrinkage Deflection—Alternate Procedures. ACI Minimum Depth of Flexural Members. Span to Depth Ratio to Account for Cracking and Sustained Load Effects. ACI Code Deflection Provisions—Examples. *Selected References. Problems.*

**15 / Length Effects on Columns**

555

General. Buckling of Concentrically Loaded Columns. Equivalent Pin-End Lengths. Moment Magnification—Simplified Treatment for Members in Single Curvature without End Translation (Sidesway). Moment Magnification—Members Subjected to End Moments Only; No Joint Translation. Moment Magnification—Members with Sidesway Possible. Beam-Columns in Rigid Frames. Alignment Charts for Effective Length Factor  $k$ . Interaction Diagrams—Effects of Slenderness. Strength Reduction Factors. ACI Code—Moment Magnifier Approximate Method. ACI Code—Slenderness Ratio Limitations. ACI Code—General Analysis. Restraining Effect of Beams. Examples. *Selected References. Problems.*

**16 / Design of Flat Slabs**

General Description. Statical Analysis of a Typical Interior Panel. Methods of Design. Nominal Requirements for Slab Thickness and Size of Edge Beams, Column Capital, and Drop Panel. Basis for Direct Design Method. Direct Design Method—Longitudinal Distribution of Total Static Moment. Direct Design Method—Effect of Pattern Loadings on Positive Moment. Direct Design Method—Procedure for Computation of Longitudinal Moments. Direct Design Method—Transverse Distribution of Longitudinal Moment. Design of Slab Thickness and Reinforcement for Flexure. Shear Stresses around an Interior Column. Shear Reinforcement in Flat

Plate Floors. Direct Design Method—Moments in Columns. Transfer of Moments to Columns. Openings in Flat Slabs. The Equivalent Frame Method. *Selected References. Problems.*

## 17 / Design of Two-Way Slabs

695

General Description. Design Procedure and Example. Limitations for Direct Design Method. Minimum Slab Thickness for Deflection Control. Direct Design Method—Total Static Design Moment. Direct Design Method—Longitudinal Distribution of Total Static Design Moment. Direct Design Method—Transverse Distribution of Longitudinal Moment. Slab Thickness Requirement in Flexure and Shear. Beam Size Requirement in Flexure and Shear. Reinforcement in Slab. The Equivalent Frame Method. *Selected References. Problems.*

## 18 / Yield Line Theory of Slabs

Introduction. General Concept. Fundamental Assumptions. Methods of Analysis. Yield Line Analysis of One-Way Slabs. Work Done by Yield Line Moments in Rigid Body Rotation of Slab Segment. Nodal Force at Intersection of Yield Line with Free Edge. Nodal Forces at Intersection of Three Yield Lines. Yield Line Analysis of Rectangular Two-Way Slabs. Corner Effects in Rectangular Slabs. Application of Yield Line Analysis to Special Cases. *Selected References. Problems.*

## 19 / Torsion

General. Torsional Stress in Homogeneous Sections. Torsional Stiffness of Homogeneous Sections. Spiral Reinforcement in Circular Concrete Members Subjected to Torsion. Ultimate Strength of Plain Concrete Rectangular Sections in Torsion. Strength of Reinforced Concrete Rectangular Sections in Torsion—Skew Bending Theory. Strength of Reinforced Concrete Rectangular Sections in Torsion—Space Truss Analogy. Strength of Sections in Combined Bending and Torsion. Strength of Sections in Combined Shear and Torsion. Strength Interaction Surface for Combined Bending, Shear, and Torsion. Nominal Torsional Stress—ACI Code. Torsional Strength of Concrete and Hoop Reinforcement—ACI Code. Provisions for Combined Torsion with Shear or Bending—ACI Code. Minimum Requirements for Torsional Reinforcement—ACI Code. Examples. Torsional Stiffness Effects on Compatibility Torsion. *Selected References. Problems.*

## 20 / Footings

Purpose of Footings. Bearing Capacity of Soil. Types of Footings. Types of Failure of Footings. Shear Strength of Footings. Flexural Strength of Footings and Development of Reinforcement. Proportioning Footing Areas for Equal Settlement. Investigation of Square Spread Footings. Design of Square Spread Footings. Design of Rectangular Footings. Design of Plain and Reinforced Concrete Wall Footings. Combined Footings. Design of Combined Footings. Pile Footings. *Selected References. Problems.*

## 21 / Introduction to Prestressed Concrete

Prestress. Historical Background. Advantages and Disadvantages of Prestressed Concrete Construction. Pretension and Posttension Beam Behavior. Prestress of Flexural Members—Tendons Having Varying Amounts of Eccentricity. Three Basic Concepts of Prestressed Concrete. Loss of Prestress. Ultimate Strength of Flexural Members—ACI Code. Cracking Moment. Shear Strength of Members without Web Reinforcement. Web Reinforcement for Prestressed Concrete Beams. Development of Reinforcement. Additional Topics. *Selected References. Problems.*