

Contents

EXPERIMENT

1 VOM MEASUREMENTS

D-C Voltmeter Loading Effects. Voltmeter Input Resistance. A Method for Eliminating Effects of Voltmeter Circuit Loading. D-C Current Meter Loading Effects. A-C Voltmeter Circuit Loading. Output Function of a VOM. Frequency Characteristics of a VOM. Some Voltmeter Applications.

2 VTVM CHARACTERISTICS AND MEASUREMENTS

Description and Operation. Input Characteristics and Circuit Loading Effects. RMS and Peak-to-peak Measurements. VTVM Probes. Decibel (db) Measurements. Laboratory Standard High-sensitivity VTVM.

3 CAPACITANCE AND RESISTANCE MEASUREMENTS

Using an Impedance Bridge to Measure Capacitance. Measurements with the General-purpose Capacitor Checker. Large Resistance Measurements with VTVM. Pulse Testing. Resistance Measurements with the Impedance Bridge.

4 MEASUREMENT OF INDUCTANCE AND Q

Using an Impedance Bridge to Measure Inductance. Effect of Q on the Resonant Rise of Voltage in a Series Resonant Circuit; The O Meter.

5 OSCILLOSCOPE CHARACTERISTICS AND CALIBRATION

Operation. Oscilloscope Characteristics. Operating Controls. Input Jacks and Terminals. Procedure for Adjusting the Operating Controls. Oscilloscope Probes. Calibrating the Vertical Amplifiers of an Oscilloscope.

6 OSCILLOSCOPE CHARACTERISTICS AND MEASUREMENTS

Vertical-amplifier Bandwidth Characteristics. A-C versus D-C Oscilloscopes. Frequency Measurements Using Lissajous Patterns. Phase Measurements with Lissajous Patterns.

EXPERIMENT

7 OSCILLOSCOPE CHARACTERISTICS AND APPLICATIONS

Sweep Linearity. Direct Phase Measurements Using External Synchronization. Oscilloscope Used as a Null Indicator. Signal Tracing in Electronic Circuits.

8 FAMILIARIZATION WITH LABORATORY STANDARD OSCILLOSCOPES

9 MEASUREMENT WITH LABORATORY STANDARD OSCILLOSCOPES

Voltage Measurements. Sweep-expansion Techniques for Time Measurements. Delayed Sweep. Dual-trace Observation of Time-related Waveforms. Output Pulses.

10 CHARACTERISTICS AND APPLICATIONS OF SINE- AND SQUARE-WAVE GENERATORS

A-F Sine-wave Generator. Square-wave Generators. Calibration Accuracy. Measuring Gain and Frequency Response in A-F Circuits.

11 CHARACTERISTICS, CALIBRATION, AND APPLICATIONS OF R-F SINE-WAVE GENERATORS

Characteristics of R-F Sine-wave Generators. Marker Generator. Applications.

12 CHARACTERISTICS AND USE OF SWEEP-FREQUENCY GENERATORS

Characteristics. Sweep-generator Controls. Output Characteristics. Checking Response Curves. Marking the Response Curve. Marker Injection.

13 LINEARITY AND COLOR-BAR GENERATORS

Linearity Generator. Color-bar Generator.

14 TUBE, TRANSISTOR, AND SOLID-STATE-DIODE TESTERS

Tube Testers. Controls and Switches. Automatic Tube Testers. CRT Tester. Transistor Testers.

15 MISCELLANEOUS TEST INSTRUMENTS AND APPLICATIONS

Pulse Generator. Variable-speed Electronic Stroboscope. Heterodyne Frequency Meter. Grid-dip Meter.