

**INDEX****A**

2-amino-2methyl-1propanol (a neutralizing amine), 349  
 Acidity determination, 444-447  
   - Methyl orange acidity, 445-446  
   - Total acidity, 445-446  
   - Free mineral acidity, 447  
 Activated magnesia, 281  
 Activated silica, 106-107  
 After precipitation, 47, 127  
 After-boiler section, 5  
 Algal slimes in softener - removal, 191  
 Alkali-iodide-azide reagent, 484  
 Alkaline boilout, 389-390, 399  
 Alkaline cleaning solution, 389  
 Alkalinity determination 452-457  
   - Phenolphthalein alkalinity, 453-454  
   - Total alkalinity, 454  
   - calculation of three forms of alkalinity, 454-456  
   - hydroxide alkalinity-B value-detrn, 456-457  
 All volatile Treatment, 346  
 Alum addition in softening, 126  
 Aluminium hydroxide gel  
   - preparation, 287  
 Aluminium sulfate (Alum), 101-102, 126  
 Alum stock soln for Jar test, 504  
 Ammonia 31, 34  
   - corrosion due to, 61  
   - and condensate corrosion, 70  
   - as regenerant, 136  
   - addition in all volatile treatment, 346  
   - to prevent condensate corrosion, 348  
   - addition to prevent pre-boiler corrosion, 352  
 Ammonia-ammonium chloride buffer, 459, 496  
 Ammoniated citric acid, 392  
 Ammonium bifluoride, 393  
 Ammonium bromate, 392  
 Ammonium molybdate soln for phosphate detn, 490  
 Ammonium molybdate, 10% soln, for silica, 480  
 Ammonium salts of EDTA, 392, 395  
 AMP (a phosphonate), 269, 312, 326  
 Angstrom unit, 255  
 Anion dealkalization, 201-203  
 Anionic surfactants, 275  
 Antifoams, 91, 94, 95, 356

- feeding, 314  
 - polyamides, 356  
   - recommended dosage, 356  
 - polyoxy alkylene glycols, 356  
   - recommended dosage, 356  
 - silicones, 356  
 Antiscalants, 94-95, 269  
   - phosphonates in RO process, 269  
 Anti telescoping device (ATD), 257  
 Artificial standard soln for silica detn, 480  
 ASME Standards  
   - for boiler water, 84  
   - for feed water, 84  
   - for steam, 84  
 Attemperators - See Desuperheaters,  
 Attrition losses, 160  
 Auxiliary chemicals for coagulation, 104-105

**B**

Bacterial slimes in softener - removal, 190, 191  
 Bare tube economizer, 7  
 Barium chloride, 5% soln, 472  
 Barium chloride, crystals, 474  
 Bed volume, 141  
 Bentonite, 107  
 Biofouling of RO membranes 270-271  
 Blends of neutralizing and film forming amines, 351, 353  
 Blowdown, 361-366  
   - advantages and disadvantages, 364  
   - bottom, 363-364  
   - calculations of 364-366, 374-376, 477-478  
   - continuous, 361-363  
   - definition, 24  
   - intermittent, 363  
 Blowdown ratio, 25  
 Boiler, 3  
   - A-type 17, 18  
   - classification, 11-23  
   - definition, 3  
   - D-type, 17-18  
   - fire tube, 12, 13-15  
   - flexitube 19  
   - fluidized bed combustion, 22

- forced circulation, 21
  - high pressure, 11
  - horizontal return tube, 13-15
  - hot water, 22
  - low pressure, 11
  - natural circulation, 21
  - O-type, 17, 18
  - package 17-19, 20
  - pulverized coal, 21-22
  - spreader-stoker, 21
  - supercritical, 12
  - waste heat, 23
  - water tube, 12, 15-16
  - Boiler blowdown - See blow down
  - Boiler capacity rating, 24
  - Boiler clearing, 391-399
  - Boiler efficiency, 24
  - Boiler evaporation ratio, 24
  - Boiler horsepower, 24
  - Boiler lay-up, 400-402
    - dry lay-up 400, 401, 402
    - wet lay-up, 400-401, 402
  - Boiler maintenance, 403-405
  - Boiler section, 5
  - Boiler startup, 389-390
    - from dry lay-up, 390
    - from wet lay-up, 390
  - Boiler tube failure - See Tube Failure
  - Boiler water
    - definition, 27
    - quality requirements, 83-84, 87
  - Borax soln, 1%, 480
  - Breakage of crosslinking, 164-165
  - Breakthrough, 154
  - Brine dosage determination, 182-183
  - Brining, 181-182
  - British thermal unit, 25
  
  - C**
  - Calcium carbonate scale, 31-32, 37-38, 47
  - Calcium chloride and corrosion, 60, 68
  - Calcium determination, 463-464
  - Calcium hydroxide-See Hydrated lime
  - Calcium nitrate
    - in the prevention of economizer corrosion, 355
  - Calcium nitrate and corrosion, 60
  - Calcium oxide-See Lime
  - Calcium phosphate, 39
  - Calcium standard soln, 458
  - Calcium sulfate scale, 32, 38
  - Carbohydrazide, 337
  - Carbonate hardness, 460, 461
  - Carbondioxide corrosion, 57-58, 69, 75
    - prevention, 331-332
  - Carbondioxide determination-See Free carbondioxide determination
  - Carboxy methyl cellulose 324
  - Carryover, 27, 36, 48-49, 79-80
    - definition, 27
    - effects of, 80
    - of silica, 45-46
    - prevention, 357-358
  - Caustic embrittlement, 64, 317, 321, 332
    - prevention of, 65, 339-346
      - by addition of inhibitors, 340-341
      - by congruent phosphate-pH method, 344-345
      - by co-ordinated phosphate-pH program, 341-344
      - by zero solids treatment, 346
    - of rotors and turbines, 48
    - mechanism, 64
  - Caustic gouging, 65, 290
    - mechanism, 65
    - prevention of, 66, 339-346
      - by congruent-pH method, 344-345
      - by co-ordinated phosphate, -pH method, 341-344
      - by zero solids treatment, 346
  - Caustic soda
    - as regenerant, 135, 136, 156, 227, 284
    - feeding, 313
    - rayon grade, 284
    - requirements, calculations, 382-383
  - Caustic soda solution, preparation, 415-416
  - Caustic soda treatment for filter sand 113
  - Channeling, 165
  - Chelant corrosion, 63, 323-324
  - Chelant dose, 325
    - determination, 325-326
  - Chelant program, 322-326
    - addition of polymers, 324
    - chelant dose, 325
    - limitations, 323
    - maintenance of alkalinity residual, 324
-

- phosphate-chelant-polymer combination, 326
  - precautions, 324
  - Chelants, 91, 94
    - EDTA, 91, 322, 323
    - NTA, 91, 322, 323
    - advantages, 322
    - dose, 325
    - feeding point, 313, 325, 354
  - Chelant treatment-See Chelant program
  - Chemical cleaning methods, 391
  - Chemical cleaning solutions, 392-396
    - EDTA cleaning solution, 395-396
    - inhibited hydrochloric acid, 392
    - hydrochloric acid cleaning solution
      - for carbonate and phosphate deposits, 393
      - for the removal of iron and silicate scales, 393
      - for the removal of copper, 393
    - inhibited sulfamic acid, 394-395
    - passivating solution, 394
  - Chemical feeders, 126, 417-422
    - dry chemical feeders, 422
    - solution feeders, 417-421
  - Chemical feeding
    - antifoams, 314
    - caustic soda, 313
    - chelants, 313
    - filming amines, 314
    - neutralizing amines, 314
    - oxygen scavengers, 313
    - polymeric dispersant, 314
    - phosphates, 313, 320
    - soda ash, 313
  - Chemical feed system
    - computerized, 314
  - Chemical pot feeder, 314-315
  - Chemicals handling and storage, 409-411
    - storing chemical solutions, 416
  - Chloride determination, 476-478
  - Chlorine treatment for filter sand, 113
  - Chloroform, 470
  - Citric acid, 275, 390
  - Cleaning in place (CIP), 257
  - Cleaning of superheaters, 399
  - Cleaning of turbines, 399
  - Cleaning procedure, 396-399
    - EDTA cleaning, 398-399
    - hydrochloric acid cleaning, 396-398
  - Clumping of resins, 251-252
  - Coagulant demand determination, 504-505
  - Coagulants, 100-104, 126
    - aluminium surface (alum), 101-102
    - organic polymers, 103-104
    - polyaluminium chloride, 101, 103
    - sodium aluminate, 102-103
  - Coagulation, 100-109
  - Coagulation equipments, 107-109
  - Coalescing oil filter, 286, 288
  - Cocurrent regeneration, 158-159
  - Cold lime-soda softening, 115-128
    - limitations, 126
    - variations, 126-128
  - Collection of samples, 430-431
    - sampling of boiler water, 432-433
  - Colloidal silica, 138, 236, 280
  - Concentrate (reject, retentate), 256
  - Concentrate flow, 257
  - Concentration polarization, 257, 274
  - Condensate
    - definition, 26
  - Condensate corrosion, 69-70
    - prevention, 348, 351
  - Condensate filtration, 353
  - Condensate polishing - See condensate treatment
  - Condensate treatment, 95-96, 289-293
    - magnetic filters, 292-293
    - mixed bed polishing, 290-291
    - powdex polishing, 292
  - Condensed tannins, 309, 310
  - Conditioner, 94, 95
  - Conditioning reagent, 474
  - Congruent phosphate-pH method, 341, 344-345 (congruent control)
  - Continuous sand filters, 114
  - Control parameters and testing schedule, 425-429
    - for boiler blowdown, 428
    - for boiler water, 428
    - for condensate, 428
    - for feed water, 428
  - Control parameters for treatment processes
    - cation exchange softening, 426
    - demineralization, 426
    - lime soda softening, 426
  - Conversion factors
    - calcium carbonate equivalents, 371
    - conversion to calcium carbonate, 369
    - gram per litre to equivalent per litre, 369
    - gram to equivalent, 369
-

- milligram per litre to milli equivalent per litre,  
369

- Co-ordinated phosphate-pH program, 341-344  
Copper, 48  
Copper determination, 470-472  
Copperoxide, 289, 290  
Copper standard soln, 471  
Copper stock soln, 470  
Corrosion  
- acidic, 52-53  
- by ammonia, 61, 70, 71  
- by calcium chloride, 60, 68  
- by calcium nitrate, 60  
- by hydrogen sulfide, 61, 70  
- by lubricating oil, 76  
- by magnesium chloride, 59, 68  
- by magnesium nitrate, 59  
- by magnesium sulfate, 60  
- by peaty matter, 61  
- by sulfurdioxide, 61, 70  
- caused by boiler sludge, 461-462  
- caused by carbon dioxide, 57-58, 70, 71, 75  
- caused by chelants, 63  
- caused by unstable salts, 59-60  
- condensate, 69-70  
- definition, 35  
- dissolved oxygen, 54-56, 70, 71, 73  
- due to ammonia, 61  
- economizer, 73-74  
- general, 52-53  
- preboiler, 71-72  
- superheater, 75-76  
- turbine, 75-76  
Corrosion by unstable salts, 59-60  
Corrosion due to low pH  
- prevention, 331-332  
Countercurrent regeneration, 158-159  
Cracking of resin, 160  
Cross flow filtration - See Reverse Osmosis  
Cycles of concentration  
- definition, 25  
- calculations, 374-377, 477-478  
Cyclohexylamine, 53, 91, 353  
- addition for the prevention of condensate  
corrosion, 91  
- addition in all volatile treatment, 346  
- properties, 349

## D

- 2-dimethyl amino-2-methyl-1-propanol, 349  
(a neutralizing amine)  
Deaerating heaters, 294, 295-298  
- atomizing type, 296  
- spray and tray type, 297  
- spray type, 296  
- trouble shooting, 299-300  
Deaeration, 294-300, 352  
Deaerators, 5, 294-300  
- Types of deaerators, 294  
- maintenance, 299  
Dealkalization, 130, 145, 193-204  
- and softening, 193  
- anion dealkalization, 197, 201-203  
- applications, 193  
- limitations, 196  
- split stream, 197, 198-201  
- variants, 196-203  
- with weak acid cation and softener, 197-198  
Declumping of resins 252  
Degasser, 223-224  
Deionized distilled water, 466  
Demineralization, 130, 145-146, 205-245  
- checking the functioning of exchangers, 230  
- control tests, 234  
- degasser, 223-224  
- exchanger units, 222  
- mixed bed, 223  
- problems associated with, 235  
- regenerant waste disposal, 229-230  
- regeneration, 226-228  
- resins used for, 207-209  
- service run, 226  
- systems, 209, 222  
Demineralization plants  
- care and maintenance, 237-238  
- trouble shooting, 238-244  
Descaling, 391-399  
Desuperheaters, 8-9  
Diastearoyl ethylene diamide, 356  
Diethyl hydroxyl amine (DEHA), 337  
Diethylamino ethanol (DEAE), 53  
- properties, 349  
- in the prevention of condensate corrosion, 349  
Dilution of acids, 415  
Dioctadecyl amine, 91  
Dioctadecylamine, 351

Dioleyl piperazine, 356  
Disodium hydrogen phosphate, 318, 319, 342, 344  
Dispersants, 309-312, 344  
- feeding of, 314  
- natural, 309-310  
- synthetic, 310-311  
Disposal of spent brine, 184-185  
Dissolved oxygen, 33-34  
Dissolved oxygen corrosion, 54-56 (pitting corrosion)  
- prevention of, 333-338  
Dissolved oxygen determination, 483-485  
Dissolved solids, determination, 439-440  
Dolomitic lime, 281  
Dosage of chemicals-determination, 380-385  
Dry lay-up, 400, 401, 402

## E

Economizer, 6, 47, 354  
- baretube, 7  
- extended surface, 7  
- scale formation, 47  
Economizer corrosion, 73-74  
- prevention of, 354-355  
EDTA cleaning solution, 395-396  
EDTA titrant 0.02N, 458, 463  
EDTA working standard soln, 497  
Electrical conductivity-determination, 437-438  
- neutralized conductivity, 438  
Equivalent Mineral Acidity(EMA), 230, 231, 232  
- determination of, 451  
Eriochrome Black-T indicator, 459, 496  
Erythorbic acid, 337  
Ethylenediamine, 399  
Ethylene Diamine Tetra Acetic acid (EDTA), 91, 275, 322, 323  
Evaporation, 278  
Expression of results, 434-436  
Extended surface economizer, 7  
External treatment, 26-27, 89-90, 92, 99

## F

Fast rinse, 157  
Feed flow, 258

Feed water, 26-27  
- definition, 26, 257  
- quality requirements, 83-86  
Feedwater Preheater, 5  
Ferric sulfate, 282, 283  
Film forming amines-See filming amines  
Filming amines, 350-351  
- disadvantages, 351  
- feeding, 314  
- in the prevention of condensate corrosion, 350-351

Filter sand, 111  
- cleaning by caustic soda, 113  
- cleaning by chlorine, 113  
- preservation of, 113-114  
- removal and filling, 114

Filtration, 110-114  
- continuous sand filters, 114  
- new developments, 114

Firetube boilers, 12, 13-15

Flash steam, 362

Flexitube boiler, 19

Flocculation aids, 105-107  
- activated silica, 106-107  
- bentonite, 107  
- polyelectrolyte, 105-106

Floc former and settling basins, 107, 108

Fluidized bed combustion boilers, 22

Flux, 258

Foaming, 36, 49, 77  
- prevention of, 356

Forced circulation boiler, 21

Fouling Index-See Silt Density Index

Free carbondioxide determination, 448-450  
- in degasser effluent, 449-450  
- in steam, 450

Free Mineral Acidity (FMA), 231, 446  
- determination, 446-447

## G

Gas pockets, 236

Gel type ion-exchange resins (microporous resins), 132-137  
- strong acid cation, 134  
- strong base anion, 135  
- weak acid cation, 134-135  
- weak base anion, 135-136

**H**

## Hardness

- classification, 460
- conversion factors, 462
- determination, 458-462
- units, 462

## Hardness removal, 93

## Hardness (Total) determination, 458-462

## Heater deaerators-See Deaerating heaters

## Heat Recovery Steam Generators (HRSG)-See Waste heat boilers.

## HEDP (a phosphonate), 269, 309, 312, 326

## Hexadecylamine (a film forming amine), 91, 351

## Hollow-fat fibre, 263

## Hollow fine-fibre module-See Hollow fibre module

## Hollow fibre module, 261, 263, 265

## Horizontal-return tube boiler, 13

## Hot lime-soda softening, 128-129

- for silica removal, 280-281

## Hotwater boilers, 22

## Hydrated dolomitic lime, 281

## Hydrated lime, 104, 115, 116, 281

## Hydrazine, 91

- addition in all volatile treatment, 346
- advantages, 337
- as oxygen scavenger, 336-338, 353
- disadvantages, 337
- feeding point, 336, 353
- recommended residuals in boiler water, 337

## Hydrazine, determination, 494-495

## Hydrazine standard soln, 494

## Hydrazine stock solun, 494

## Hydrazine sulfate, 337

## Hydrochloric acid

- 0.5N, 494
- 1+1, 468, 472, 480

## Hydrochloric acid as regenerant, 134, 135, 155, 195, 198, 201, 227, 248

## Hydrochloric acid cleaning solution

- for the removal of carbonate and phosphate deposits, 393
- for the removal of copper, 393
- for the removal of iron and silicate scales, 393

## Hydrochloric acid (inhibited)

- for acid cleaning, 389, 392

## Hydrogen embrittlement, 67-68

## Hydrogen sulfide

- and condensate corrosion, 70

- corrosion due to, 61

## Hydroquinone, 337,

## Hydroxide alkalinity-B value, detn, 456-457

## Hydroxyacetic-formic acid, 390, 392

## Hydroxyethyl cellulose, 283

## Hydroxylamine, 337

## Hydroxyl amine hydrochloride soln, 470

## Hydroxylamine hydrosulfate, 399

## Hyperfiltration, 258

**I**

## Induced air floatation (for oil removal), 286, 288

## Inhibited hydrochloric acid-See hydrochloric acid (inhibited)

## Inhibited sulfamic acid-See sulfamic acid (inhibited)

## Inhibitors added to hydrochloric acid, 392

- acridine, 392
- imidazoline, 392
- hexamine, 392
- pyridine, 392
- quinoline, 392
- triamyl amine, 392

## Intercrystalline cracking-See Caustic embrittlement

## Internal treatment, 88, 89, 91, 92, 303-304

- for oil removal, 91, 288

## Ion exchange capacity (Resin capacity), 141-143

## Ion exchange method of softening-See softening by ion exchange method

## Ion exchange plants

- care and maintenance, 166
- for dealkalization, 194, 198, 201
- for demineralization, 207-209
- for softening, 172

## Ion exchange resins, 130-141

- gel type resins (microporous resins), 132-137
  - base polymer, 131
  - functional group, 131
  - strong acid cation, 134, 208
  - strong base anion, 135, 208-209
  - weak acid cation, 134-135, 194, 208
  - weak base anion, 135-136, 210
- macroporous resins
  - anion macroporous, 138
  - as organic scavengers, 138
  - cation macroporous, 138

Ion exchange resins, 130-141

- cracking of, 160
- density, 140
- disinfection, 167-168
- life span, 137
- maximum operating temperature, 137
- particle size, 139
- porosity, 139
- protection during storage, 169
- removal of algal slimes, 168
- resin capacity(ion exchange capacity), 141
- salt splitting capacity, 141
- stability of resin, 146, 151
- strong base capacity, 141
- water regain, 140

Ion exchange treatment

- associated problems, 160-166
- attrition losses, 160
- break through, 154
- degradation of, 165
- hydraulic considerations, 150-151
- important parameters, 141-145
- leakage, 150
- operation sequences, 152-158
- practical considerations, 145-152
- regeneration, 154, 158

Ionic load (ion exchange load), 143-144

Iron oxide, 289, 290

Iron (Total) determination, 468-469

Iron standard soln, 468

Iron stock soln, 468

Isoascorbic acid, 337

Isoporous resin, 132

Isopropyl alcohol, 471

## J

Jar test-See Coagulant demand determination

## L

Langelier Saturation Index, 500-502

Layered bed, 218, 219, 220

Leakage, 146, 150

- of sodium, 231, 232

- of silica, 235

Leakage of hardness, 186

Lignin, 91, 286, 309, 310, 311, 317, 321, 328

Lignin sulfonate, 340

Lime, 109, 115, 116, 281

Lime dose for softening calculations, 118-119, 129-121, 122

Lime-soda softening, 115-129

- cold lime-soda softening, 115-128

- hot lime-soda softening, 128-129

Lime stock soln for Jar test, 504

Loss of resin capacity, 164-165

## M

Macroporous resins

- anion macroporous, 138

- as organic scavengers, 138-139

- cation macroporous, 138

- cleaning, 168-169

- for condensate polishing, 290

Magnesia, 280, 281

Magnesium chloride and corrosion, 59

Magnesium determination, 465

Magnesium hydroxide sludge, 32, 38

Magnesium nitrate and corrosion, 60

Magnesium oxide

- in the prevention of economizer corrosion, 355

Magnesium silicate sludge, 39

Magnesium standard soln, 496

Magnesium sulfate and corrosion, 60

Magnesium sulfate soln, 483

Makeup water

- definition, 26

- requirements calculations, 377-379

Manganous sulfate soln, 483

Mechanical removal of oxygen-See Deaeration

Membrane foulants, 276

Methyl ethyl ketoxamine, 337

Methyl orange acidity, 445-446

Methyl orange alkalinity, 454

Methyl orange indicator soln, 445

Methyl polysiloxane (antifoam), 356

Methyl red indicator soln, 472

Micro filtration, 255

Misting, 78-79

Mixed bed deionization, 223, 246-254

- mixed bed units, 246

- for condensate polishing, 290-292
  - problems associated with mixed beds, 251
    - bad mixing, 253
    - clumping of resins, 251
    - degradation of resins, 254
    - fouling of resins, 253
    - imperfect mixing, 252
    - imperfect separation, 252
    - mechanical problems, 254
  - recent advances, 250
  - regeneration, 251
    - external regeneration, 250
    - insitu regeneration (two step method), 248, 249
    - offline regeneration, 250
    - simultaneous method, 248
- Mixed bed polishing, 290
- Mixed indicator, 453
- Morpholine, 53, 91, 346, 353
  - addition in all volatile treatment, 346
  - properties, 349
- Mud drum, 5-6
- Murexide indicator, 463

## N

- N, N' - dihexa decyl adipamide, 356
- N, N' - diocta decyl sebacamide, 356
- Nano filtration, 255
- Natural circulation boiler, 21
- Natural dispersants, 309-310
  - condensed tannins, 309, 310
  - lignins, 309
  - quebracho, 309
  - sodium alginate, 309
  - sodium mannuronate, 309
  - starch, 309
  - sulfonated lignins, 309, 310
- Neo cuproin soln, 470
- Neutralized conductivity, 438
- Neutralizing amine, 53, 348-350, 353
  - feeding, 314, 350
  - in the prevention of condensate corrosion, 348-350
  - properties, 349
  - requirements, calculations of, 384-385
- Nitrilo Triacetic Acid (NTA), 91, 322, 323
- Non-carbonate hardness, 460, 461

- Non-ionic polymers, 283
- Non-ionic surfactants, 275
- Non-precipitation program, 316, 322-237

## O

- Octadecylamine(a film forming amine), 91, 350
- Oil balls, 286, 288
  - prevention of, 288, 312
- Oils & grease, 488-489
- Open heaters, 294, 295
- Operator's performance and training, 404-405
- Organic phosphates (See Phosphonates)
- Organic polymers-See Polymers
- Organic polymers as coagulants, 103-104
- Orthophosphates, 318
  - addition in congruent phosphate-pH method, 344-345
  - addition in co-ordinated phosphate-pH program, 342-344
  - addition in internal treatment for scale prevention, 317-320
  - limitations to use in scale prevention, 319

- Output between regenerations (OBR), 145
- Oxalic acid soln, 10%, 480
- Oxygen absorbed-determination, 486-487
- Oxygen (dissolved)-See Dissolved Oxygen
- Oxygen scavengers, 94, 333, 336-338, 352-353
  - carbonylhydrazide, 337
  - diethyl hydroxyl amine (DEHA), 337
  - erythorbic acid, 337
  - feeding, 313, 334-335, 336
  - hydrazine, 336-337
  - hydrazine sulfate, 337
  - hydroquinone, 337
  - hydroxylamine, 337
  - iso ascorbic acid, 337
  - methyl ethyl ketoxamine, 337
  - sodium sulfite, 333-336

## P

- Package boiler, 17-19, 20
  - A-type, 17,18
  - D-type, 17-18
  - O-type, 17, 18



- Para dimethyl amino benzaldehyde soln, 494
- Passivating solution, 394
- Patton and Reeder's indicator, 463
- PBTC (a phosphonate), 269, 309, 312, 326
- Percentage of moisture in steam - determination, 358
- Permanganate value - determination, 486-487
- Permeate, 256, 258
- Petroleum ether, 488
- pH 4 buffer solution, 442
- pH 7 buffer solution, 442
- pH 9 buffer solution, 442
- pH recommended for corrosion control, 53
- pH value-determination, 441-443
- Phenolphthalein acidity, 445-446
- Phenolphthalein alkalinity, 453-454
- Phenolphthalein indicator soln, 445, 448, 453, 490
- Phosphate determination, 490-491
- Phosphate hideout, 40, 320
- Phosphate programs, 341-345
  - congruent phosphate-pH method, 341, 344-345
  - co-ordinated phosphate-pH program, 341-344
- Phosphate requirement calculation sn, 381-382
- Phosphates,
  - orthophosphates, 318, 319
    - disodium hydrogen phosphate, 318, 319, 342, 344
    - sodium dihydrogen phosphate, 318, 319, 344
    - trisodium phosphate, 318, 319, 342, 344
  - polyphosphates, 318, 320, 343
    - sodium hexa meta phosphate, 318, 320, 321
    - sodium tripolyphosphate, 318, 321
    - tetra sodium pyrophosphate, 318
- Phosphates commonly used - properties, 318
- Phosphate standard soln, 490
- Phosphate stock soln, 490
- Phosphate treatment, 316, 317-321
  - addition of polymers, 321
  - commonly used phosphates, 318
  - feeding point 313, 320
  - limitations for ortho phosphates, 319-320
  - phosphate requirement - calculations of, 381-382
  - polyphosphates, 320
- Phosphonate program, 326-327
- Phosphonates, 91, 269, 309, 312, 326
  - AMP (Amino-trimethylene phosphonic acid), 369, 312, 326
  - HEDP (1-hydroxy ethylidene 1, 1, diphosphonic acid), 269, 309, 312, 236
  - PBTC (2-phosphono butane-1, 2, 4-tricarboxylic acid), 269, 309, 312, 326
  - as antiscalants in RO process, 269
- Phosphoric acid for DO detn, 484
- Pipes for chemical solutions, 421
- Pitting corrosion, 54-56
  - prevention, 333-338
- Plate and Frame module, 261
- Polyacrylamide, 105, 106, 310
- Polyacrylate, 91, 269, 286, 288, 307, 308-309, 310, 311, 317, 324, 328
- Polyaluminium chloride (PAC), 103
- Polyamide antifoams, 91, 356
  - diastearoyl ethylene diamide, 356
  - dioleyl piperazine, 356
  - N, N' - diocta decyl sebacamide, 356
  - N, N' - dihexa decyl adipamide, 356
  - dosage, 356
- Polyelectrolytes, 105-106
- Polyetheramide-polysulfone composite membranes, 262
- Polyethylene imine membranes, 260
- Polyfuran membranes, 260
- Polymaleate, 310, 324
- Polymer addition in chelant treatment, 324
- Polymer addition in sludge conditioning, 329
- Polymeric flocculants - See Polyelectrolytes
- Polymer requirements - calculations, 383-384
- Polymers, 103-104, 305-312, 321
  - anionic, 306, 307, 310
  - addition in chelant program, 324, 326
  - addition in phosphate treatment, 321
  - addition in sludge conditioning, 329
  - as coagulants, 103-104
  - as dispersants, 309-310
  - as scale inhibitors, 308-309
  - as sludge conditioners, 311-312
  - cationic, 306, 307
  - non-ionic, 306, 307, 308, 310
- Polymethacrylate, 91, 307, 308-309, 310, 311, 317, 324, 328
- Polyoxy alkylene glycols (antifoams), 91, 356
  - dosage, 356
  - dotetra conta oxyethylene glycol, 356
  - octadeca-oxyethylene glycol, 356
- Polyphosphates, 127, 318, 320-321, 343
  - addition in co-ordinated phosphate-pH method, 343
  - addition in internal treatment, 320-321
  - addition in lime soda softening, 127
  - limitations, 320-321

- Polyvinylalcohol, 105  
Ponding, 128  
Potassium chromate indicator soln, 477  
Potassium chromate soln for silica detn, 480  
Potassium iodate-iodide soln, 492  
Potassium iodide soln, 10%, 487  
Potassium permanganate soln  
- 0.01250 N, 486  
- 0.02 N, 468  
- 0.1250 N, 486  
Powdex process (Powdex Precoat polishing)  
- for condensate treatment, 292  
- for the prevention of pre-boiler corrosion, 353  
Practical Scaling Index-See Puckorius Scaling Index  
Pre-boiler corrosion, 71-72  
- prevention, 72, 352-353  
Pre-boiler section, 5, 71-72  
Pre-boiler treatment-See External treatment  
Precipitation program, 316-321, 327  
Precoat filters (for oil removal), 286, 287, 324, 328  
Pre-operational cleaning-See Boiler start up  
Preparation of lime suspension (milk of lime), 414-415  
Preparation of solutions and suspensions, 412-416  
- preparation of caustic soda solution, 415-416  
- preparation of concentrated solutions from solid  
chemicals, 412-413  
- preparation of dilute solutions from concentrated  
solutions, 413-414  
- preparation of lime suspension, 414-415  
Pressure drop, 161  
Pressure filter, 110-113  
- preservation of filter sand, 113  
- removal of sand and gravel, 114  
Pressure units and conversion factors, 10  
Pressure vessels, 259  
Prevention of carryover, 357-358  
Prevention of caustic embrittlement and caustic gouging,  
339-346  
Prevention of corrosion  
- chelant corrosion, 347  
- condensate corrosion, 348-351  
- due to low pH, 331  
- economizer corrosion, 354-355  
- pitting corrosion, 333-338  
- preboiler corrosion, 352-353  
Prevention of foaming, 356  
Prevention of priming, 357  
Prevention of scale formation, 316-327  
Prevention of silica carryover, 356-358  
Priming, 36, 75, 77-78, 357  
- effects of, 78  
- prevention of, 357  
*Pseudomonas*, 164  
Puckorius Scaling Index (PSI), 503  
Pulverized coal boiler, 21-22
- Q**  
Quality requirements  
- for feed water, 83, 84, 86  
- for boiler water, 83, 84  
- for steam, 84  
Quebracho, 286, 309  
Quebracho tannin (as caustic embrittlement inhibitor), 340  
Quicklime - See Lime
- R**  
Rayon grade caustic soda, 284  
Recovery, 258  
Regenerant consumption, 146, 152  
Regenerant injection, 155-157  
Regenerant removal, 157, 228  
Regenerant reuse, 159-160, 229-230  
Regenerants, 155-156, 198  
Regenerant waste disposal, 159-160  
Regeneration  
- during ion exchange treatment, 154-158  
- during softening, 180-184  
- during dealkalization, 195, 201, 203  
- during demineralization, 226-229  
Regeneration capacity, 194  
Regeneration level (Regenerant level), 144  
Regeneration ratio, 144-145  
Reject-See Concentrate  
Residual chelant (EDTA) - determination 496-499  
Resin capacity (Ion exchange capacity), 141-143  
- Loss of resin capacity, 164-165  
Resin capacity units, 142  
- conversion factors, 142  
Resin fouling, 161-164, 236-237  
Reverse osmosis, 255-277  
- and ion exchange, 257  
- antiscalants used in RO, 269  
- factors affecting performance, 272-274  
- feed water requirements, 266

- identification of foulants, 276
  - maintenance of RO systems, 276-277
  - membrane cleaning, 274-275
  - membrane configurations, 261-265
  - membrane materials, 259-261
  - process details, 255-256
  - special advantages, 256-257
  - terminology, 257
  - water treatment systems, 258-259
- Reverse osmosis membranes
- cellulose acetate, 262
  - hollow fat fibres, 263
  - hollow fibre (hollow fine-fibre), 263
  - polyetheramide-polysulfone, 262
- Reverse osmosis membranes
- ageing, 274
  - biofouling, 270, 273
  - cleaning of, 274-275
  - colloidal fouling, 267-268, 273
  - deposition of metal oxides, 270
  - deterioration by hydrolysis, 274
  - plugging, 267, 273
  - scaling, 267, 268 - 270
- Ryznar Stability Index, 500-503
- 
- ## S
- Salt passage, 258
- Salt rejection, 258
- Salt splitting capacity, 141
- Sample collection, 430-431
- Sampling of boiler water, 432-433
- Saturated steam, 25
- Scale formation, 35, 37-40
- due to deposition of corrosion products, 40
  - due to evaporation, 37-38
  - due to reaction with water treatment chemicals, 39-40
  - in economizers, 47
  - in superheaters, 48-49
  - in turbines, 48-49
  - prevention of, 42-44
- Scale inhibitors, 308-309
- polyacrylate, 308, 309
  - polymaleate, 309
  - polymethacrylate, 308, 309
- Scales-See also scale formation
- Sepralators-See Spiral wound module
- Septum filters (for oil removal), 286, 287-288
- Shot feeder, 314-315
- Silica, 33, 279, 37
- volatility, 45-46
  - permissible concentrations in boiler, 280, 362
- Silica carryover, 45-46
- prevention of, 359-360
- Silica, colloidal - See Colloidal silica
- Silica determination, 479-482
- Silica leakage, 235
- Silica removal, 93, 279-285
- by cold lime-soda ferric sulfate process, 282-283, 285
  - by demineralization, 283-285
  - hot lime-soda magnesia process, 280-282, 285
  - by ultra filtration, 280
  - using macroporous resins, 138
- Silica scales, 33, 37, 38-39, 42, 43, 45, 48, 279
- Silt Density Index (SDI), 258, 260
- definition, 258
  - determination, 506-507
- Silver nitrate-nitric acid reagent, 472
- Slow rinse, 157
- Sludge blanket type coagulation and settling equipment, 109
- Sludge conditioners, 95, 311-312
- Sludge conditioning, 328-329
- coagulation method, 328, 329
  - dispersion method, 328-329
  - polymer requirements, 329
- Sludge inhibition, mechanism, 311
- Sludge inhibitors(sludge conditioners), 311-312
- natural, 311
    - lignin, 311
    - starch, 311
    - tannin, 311
  - synthetic, 6
    - copolymers of methacrylate, 311
    - polyacrylate, 311, 312
    - sulfonated styrene, 311
- Soda ash (See Sodium Carbonate)
- Soda ash dose for softening calculations, 119, 121, 122-123
- Sodium alginate, 309
- Sodium aluminate, 102-103

- addition in softening, 126
  - Sodium bisulfite, 270
  - Sodium carbonate(Soda ash), 105, 115-116, 313, 316-317, 281
    - feeding, 313
  - Sodium carbonate soln, 1N, 453
  - Sodium carbonate treatment, 316-317
  - Sodium chloride as regenerant, 134, 155, 181, 198, 201
  - Sodium citrate soln, 470
  - Sodium determination, 466-467
  - Sodium dihydrogen phosphate, 127, 318, 319, 344
  - Sodium hexametaphosphate, 127, 318, 320, 321
  - Sodium hydroxide soln,
    - 0.02N, 445
    - 0.0227N, 448
    - 1N, 448, 463
  - Sodium mannuronate, 309
  - Sodium metabisulfite, 270
  - Sodium nitrate (as caustic embrittlement inhibitor), 340
  - Sodium polyacrylate, 324
  - Sodium polymethacrylate, 324
  - Sodium slip(sodium leak), 64, 231, 232, 235
    - determination, 230-232
  - Sodium stock soln, 466
  - Sodium sulfide inhibitor, 459
  - Sodium sulfite (as oxygen scavenger), 91, 333-336
    - demerits, 335
    - dosage calculations, 334, 380-381
    - feeding point 334-335
    - recommended residuals in boiler water, 334
  - Sodium thiosulfate soln
    - 0.01250N, 486
    - 0.025N, 484
    - 0.1N, 484
    - 0.1250N, 486
  - Sodium tripolyphosphate, 127, 275, 318, 321
  - Softener capacity (water softener capacity), 179
  - Softener units, 173
    - care and maintenance, 190-191
    - design, 174-178
  - Softening by chemical method, 115-129
  - Softening by ion exchange method, 130, 145, 171-192
    - design of softeners, 174-178
    - determination of brine dosage, 182-183
    - fault diagnosis, 186-188
    - governing factors, 186-188
    - limitations, 185-186
    - operation of softeners, 178-184
    - problems associated with softening, 188-190
  - Softening-calculation, 372-373
  - Softening run, 178-180
  - Solubilizing water treatment program – See Non-precipitation program
  - Solution feeders, 417-421
    - gravity-orifice feeders, 417, 418
    - helical rotor acid feeders, 417, 421
    - pot-type feeders, 417, 419-420
    - pressure-solution acid feeders, 417, 420
    - proportional-flow solution feeders, 418-419
    - reciprocating-pump type feeders, 417, 419
  - Spiral wound module, 261, 262-263
  - Split stream dealkalization, 197, 198-201
  - Spreader-stoker boiler, 21
  - Stability of resin, 157
  - Staging RO systems, 265
  - Standard EDTA soln for residual chelant detn, 496, 497
  - Standard EDTA titrant, 0.02N soln, 458, 463
  - Standard silver nitrate titrant 0.0282 N, 476
  - Standard sodium chloride titrant 0.0282N, 476
  - Standard sulfate soln, 474
  - Stannous chloride soln, 490
  - Starch, 91, 288, 309, 311, 317, 321, 328
  - Starch indicator soln, 484, 487, 492
  - Steam drum, 5-6
  - Steam generation system, 4
  - Steam header, 6
  - Steam purity, 25
    - measurement of, 508-509
  - Steam quality, 26
  - Steam traps, 9
  - Storing chemical solutions, 416
  - Stress corrosion cracking-See Caustic embrittlement
  - Strong base capacity, 141
  - Sulfamic acid, 392
  - Sulfamic acid (inhibited), 394-395
  - Sulfite determination, 492-493
  - Sulfonated lignin, 91, 309, 310, 311, 328
  - Sulfonated styrene, 91, 310, 311, 328
  - Sulfurdioxide
    - and condensate corrosion, 70
    - and economizer corrosion, 73, 354-355
    - corrosion due to, 61
  - Sulfuric acid
    - 0.02N, 453
-

- 1N, 453
- 1+3, 487
- 1+1, 488, 492

Sulfuric acid as regenerant, 134, 135, 156, 195, 198, 227,  
248

Sulfuric acid, conc for DO detn, 484

Sulfuric acid (inhibited), 394-395

Sulfuric acid - nitric acid soln, 490

Superheated steam, 26

Super heater, 8

- cleaning of, 399
- corrosion of, 72, 75-76
- drainable superheater, 8
- pendant superheater, 8

Superheater corrosion, 75-76

Superheating, 26

Synthetic dispersants, 310-311

- copolymers of polymethacrylate, 310
- polyacrylamide, 310
- polyacrylates, 310
- polymaleates, 310
- sulfonated styrene, 310

## T

Tannin, 91, 311, 317, 321, 328, 356

Thin Film Composite membrane (TFC/TFM)-258, 260-  
261

Thiocyanate soln 10%, 468

Thiourea, 393, 394

Thorough fare regeneration, 214

Total chelant determination, 497-498

Triammonium EDTA, 395

Trisodium phosphate, 318, 319, 342, 344

Tube failure, 42

Tube settlers, 108

Tubular module, 261

Turbine cleaning, 399

Turbine corrosion, 75-76

## U

Ultra filtration, 255, 280, 286, 288

- for oil removal, 288

## V

Vacuum deaerators, 294, 295

Vapor phase corrosion inhibitors - See Neutralizing  
amines

## W

Waste heat boilers, 23

Water regain, 140

Water treatment programs, 93-96

Watertube boilers, 12, 15-16

Wet layup, 400-401, 402

## X

Xylenol orange soln, for total chelant detn, 497

## Z

Zero solids treatment-See "All volatile treatment"

Zirconyl chloride stock soln, 498

Zirconyl chloride working soln, 498